

Unscrew the purple cap from the sample collection tube. DO NOT POUR OUT THE LIQUID.



Poke spiral applicator into stool at 6 different sites. Use only enough fecal material to cover the tip of the applicator. DO NOT CLUMP, SCOOP, OR FILL THE TUBE.



Screw the applicator back into the tube and secure tightly.





