

# Proper Barcode Label Placement

Proper barcode label placement has the following characteristics:

- Label and barcode placed as close to the colored stopper as possible
- Label and barcode oriented vertical with the tube
- Label and barcode oriented so when the colored stopper is to the left, the printed information can be read from left to right
- No extra markings next to or written over the barcode

